

1	Even with batteries inserted and the power turned on, the screen display turns off quickly.	Are the batteries out of power? Try putting in new batteries.
2	The CD playback volume has become quieter than before.	Press the LEVEL key and check the CD LEVEL. Please refer to "Using guitars and mics" on page 29 of the Owner's Manual and adjust the CD playback volume.
3	Sounds other than guitar are also being canceled.	The cancel function cancels the sound in a specific position in the stereo sound field (left-right sound position). This function basically works by inverting the phase of the right and left signals and mixing them, so that all sound at the center position is cancelled. Sounds other than guitars also may be cancelled depending on the CD.
4	Even when using the cancel function, the guitar sound is not reduced much.	The default setting is set to cancel the sound at the center position. If the guitar sound on your CD is not in the center position, then it will not be cancelled. You can change the cancellation position if the guitar sound is not in the center. For details, please see "Reducing the sound of recorded guitars" on page 26 of the Owner's Manual.
5	Even when using the cancel function, the guitar sound is not reduced much.	If reverb and delay effects are used on the guitar sound that you are trying to cancel, the cancel function may not work well. Even if the central guitar sound is cancelled, the sound created by the effect may not be cancelled.
6	The guitar volume is too low.	Is the GUITAR/MIC setting set to GUITAR? Read "Using guitars and mics" on page 29 of the Owner's Manual and check the GUITAR/MIC setting. Is the INPUT dial turned up? Is the volume on the guitar turned up? Press the LEVEL key to confirm the IN LEVEL. If necessary, refer to "Using guitars and mics" on page 29 of the Owner's Manual and adjust the GUITAR level.
7	There is no sound from the guitar.	Is the guitar cord connected? Is the INPUT dial turned up? Is the guitar cord connected to the FOOT jack by mistake? Is the guitar volume turned up? Press the LEVEL key to confirm the IN LEVEL. If necessary, read "Using guitars and mics" on page 29 of the Owner's Manual and adjust the GUITAR level. Reconnect the cord to a guitar amp or similar device to check if sound is produced. If all the above can be confirmed but there is still no sound through the unit, it could be broken. Please contact a TASCAM Service Center.
8	Can the guitar effects be turned off?	Press the EFFECT key and set the BANK to "BYPASS" to turn the effects off. See "Using Built-in effects" on page 30 of the Owner's Manual.
9	Can the setting for effects and other functions be returned to the values that they had when shipped from the factory?	Press and hold the ◀◀ and ▶▶ keys simultaneously as you turn the power on to open the INITIALIZE screen at startup. Follow the instructions on screen after startup, and press the ▶/ key to restore every effect parameter, playback setting and other function to the default values that were set when the unit was purchased new.
10	The CD playback sound is uneven.	If you are using the unit's ability to change tempo without changing pitch or to change pitch without changing tempo, the CD sound undergoes special digital processing. This is not a malfunction.
11	CD playback is not possible, or a "DISC ERR" message is displayed and playback is stopped.	Are you using a disc that is non-standard, damaged, deformed or blank? Is this disc dirty? If the playback side (bottom) of the disc is dirty, wipe it clean with a soft cloth.
12	Can a CD-R/RW be played?	Playback is possible if a standard disc has been correctly recorded.
13	Can MP3s be played?	No, MP3s cannot be played.

1	電池を入れて電源を入れても、すぐに画面表示が消えてしまう。	消耗した電池を使用していませんか？ 新品の電池に交換してください。
2	CDの再生音が以前より小さくなった。	LEVELキーを押し、 CD LEVEL を確認してください。 取扱説明書28ページ「ギターやマイクを使う」をお読みいただき、CDの再生音量を調整してください。
3	ギター以外の音もキャンセルされる。	キャンセラー機能とはステレオ音源の特定の定位（左右の音の位置）の音を消そうとする機能です。基本的には右と左の音を位相反転しミックスすることにより、中央に定位する全ての音が消える方法を応用しておりますので、お使いのCDによってはギター以外の音が消えてしまう場合もあります。
4	キャンセル機能を使ってもギターの音があまり消えない。	初期設定では、中央に定位している音をキャンセルするように設定されています。お使いのCDでギターの音が中央に定位していない場合はキャンセルされません。ギターの音が中央に定位していない場合のために、キャンセルする定位を変更することができます。詳しくは取扱説明書25ページ「ギターの音を減衰させる」をお読み下さい。
5	キャンセル機能を使ってもギターの音があまり消えない。	消そうとする音にリバーブやディレイといったエフェクトが使われている場合、キャンセル機能がうまく働かない場合があります。中心となるギター音はキャンセルされますが、エフェクトの成分がキャンセルされずに残ってしまうためです。
6	ギターの音が小さい。	[GUITAR/MIC]切替はGUITARに設定されていますか？ 取扱説明書28ページ「ギターやマイクを使う」をお読みいただき、GUITAR/MICの切替えをご確認ください。 [INPUT]ダイヤルは上がっていますか？ ギターのボリュームは上がっていますか？ LEVELキーを押し、 IN LEVEL を確認して下さい。必要に応じ、取扱説明書28ページ「ギターやマイクを使う」をお読みいただき、GUITAR音量を調整してください。
7	ギターの音が出ない。	ケーブルは接続されていますか？ [INPUT]ダイヤルは上がっていますか？ [FOOT]端子に接続していませんか？ ギターのボリュームは上がっていますか？ LEVELキーを押し、 IN LEVEL を確認して下さい。 必要に応じ、取扱説明書28ページ「ギターやマイクを使う」をお読みいただき、GUITAR音量を調整してください。 接続しているケーブルをギターアンプなどに接続して音が出ることを確認して下さい。 以上のことを確認しても音が出ない場合は、本体の故障が考えられますので弊社修理センターにお問い合わせ下さい。
8	ギターのエフェクトをオフにすることはできますか？	EFFECTキーを押し、 BANK の設定を「 BYPASS 」にすることによりオフになります。 詳しくは取扱説明書30ページ「内蔵エフェクタを使う」をご確認ください。
9	エフェクトなどの設定内容を工場出荷時設定に戻すことはできますか？	◀◀、▶▶キーを同時に押しながら電源をオンすると、 INITIALIZE 画面が起動します。起動後、画面の指示に従い、▶/■キーを押すことにより、エフェクトパラメータ、各種設定などをお買い上げいただいた状態に戻すことができます。
10	CDの音がブルブル揺れたような音になる。	音程を変えずにテンポを変えたり、テンポを変えずに音程を変える機能を使用している時にCDの音に特殊なデジタル処理を行なっているためで故障ではありません。
11	CD再生ができない、あるいは、メッセージ「DISC ERR」が表示され再生停止する。	規格外、傷、変形、未録音のディスクを使用していませんか？ ディスクが汚れていませんか？ 信号記録面が汚れている場合、柔らかい布で汚れを拭き取ってください。
12	CD-R/RWは再生できますか？	規格ディスクに正しく記録されている場合、再生可能です。
13	MP3は再生できますか？	再生できません。