
NOTICE

- For stable operation of the IF-DA64, always use an external clock source as the Dante Clock Master.
 - In the Dante network, be sure to select one device only to be the network clock master, by using the “Preferred Master” and “Enable Sync to External” settings in Dante Controller.
 - When using the DA-6400 as the Dante Clock Master, **do not set** the DA-6400’s Clock Master setting to the slot where the IF-DA64 is installed.
 - When the DA-6400 is a Dante clock slave, select the slot where the IF-DA64 is installed as the DA-6400’s Clock Master.
- When the DA-6400 is started, or the FS or Dante network connection is changed, it can take several minutes for the system to stabilize.
- TASCAM recommends Shielded LAN cables (STP type) to connect the IF-DA64 to the Dante network.

ご注意

- IF-DA64を安定して使用するためには、必ずDanteネットワーク以外の外部クロックをDante Clock Masterに設定してください。
 - Dante ControllerでDante機器のいずれか一台だけPreferred MasterとEnable Sync to Externalの2つの設定にチェックを入れてください。
 - DA-6400をDante Clock Masterに設定して使用する場合は、DA-6400のClock Masterを「IF-DA64が装着されたSLOT」に**設定しない**ください。
 - DA-6400をDante Clock Slaveに設定して使用する場合は、DA-6400のClock Masterを「IF-DA64が装着されたSLOT」に設定してください。
- DA-6400の起動後、Fs変更後、Danteネットワーク接続変更後は、Danteネットワーク同期が安定するまで、数分かかる場合があります。
- IF-DA64を使用する場合は、シールドされたLANケーブル(STPケーブル)を使用して、Danteネットワークに接続することを推奨します。