

TASCAM iU2 Audio/MIDI Interface for iPhone/iPad/iPod touch

重要なお知らせ

iU2に接続したコンピューターの再起動に関して

iU2を接続したまま、お使いのコンピューターのメニューから再起動を行うとiU2の音声出力が有効にならない場合があります。その場合は、iU2のUSB接続を一度外し、再度接続を行ってください。

MIDIポート

オーディオ/MIDIアプリケーション・ソフトウェアの設定画面などから2つのMIDIポートが見える場合があります。使用可能なMIDIポートは1番目のポートのみになりますので、お使いのMIDIアプリケーション・ソフトウェアで複数のMIDIポートが選択可能な場合は、MIDIの入出力ポートとも最初のMIDIポートを選択してください。

例

- “ポート番号無し” と “ポート1” が表示される場合は、ポート番号無しを選択してください。
- “ポート1” と “ポート2” が表示される場合は、“ポート1” を選択してください。

IMPORTANT Information

Restarting the computer connected to the iU2

If you restart the computer from the Start menu on the computer's screen while iU2 is connected to the computer, the iU2 audio output may not be enabled.

In this case, disconnect the USB cable from the iU2 and then connect it again.

MIDI port

Two MIDI ports may appear on the audio/MIDI application software's setting screen.

Note only the first MIDI port can be used.

If the MIDI application software you use allows you to select more than one MIDI port, select the first MIDI input or output port.

Examples:

- If "No port number" and "Port 1" appear, select "No port number".
- If "Port 1" and "Port 2" appear, select "Port 1".